

Wall Mount Instructions

Attaching the PR 100 Wall Mount Bracket

The wall mount bracket, when attached to a Concrete or Concrete block wall must be attached securely With 1 ½ inch X ¼ inch of wedge type anchor bolts or other Expansion bolts rated at 2000 pounds or higher. When Attached to a solid wood structure use minimum 3 inch X 3/8 inch lag bolts.

Mount the Wall Mount Bracket so that the Stanchion will Align in a vertical plane and will allow a minimum 42 inch guardrail with the Adjustable Guides as required in the regulations.

Insure that the Wall Mount Bracket is securely attached and the material is solid and strong enough to adequately support the stanchion and guardrail and any load it will be required to resist.

