

SPAR-Marathon ROOFING SUPPLIES

A division of Spar Roofing & Metal Supplies Limited

TO WHOM IT MAY CONCERN

This is to certify that by following Instructions provided on the Warning Label affixed on each Roof Bracket, our 2" x 10" Roof Brackets can be used safely for intended use.



R.D. Sandal
Dec 2, 2015

R.D.Sandal (P.Eng.)

CORPORATE OFFICE

1360 Bloor Street West
Toronto, ON, Canada M6H 1P2
P: (416) 534-8421
F: (416) 534-9373

- | | | | |
|---------------------------|---------------------------|----------------|----------------|
| • Pickering, ON | • Weston (Weston Rd.), ON | • Oakville, ON | • Edmonton, AB |
| • Toronto (Bloor St.), ON | • Weston (Signet Dr.), ON | • Hamilton, ON | • Calgary, AB |
| • Toronto (Wade Ave.), ON | • Barrie, ON | • London, ON | • Winnipeg, MB |

WEB SITE: www.sparmarathon.ca

⚠ WARNING

INSTRUCTION AND SAFETY INFORMATION. Misuse of this bracket may result in injury or damage. It is the responsibility of the purchaser to ensure that all personnel using this bracket have been trained in the proper procedures and safety regulations. This bracket must be used in accordance with all local, state or provincial and federal requirements. This bracket must be used with an approved fall arrest system, and any other safety equipment as required by law. This bracket should be used only by experienced licensed tradesmen having full knowledge of its use. **MOUNTING THE BRACKET.** Place bracket 4 feet or less apart and secure each bracket with three 16 penny (3 inch common round shank) nails to roof joists. The bracket must fit the pitch of the roof so that work platform is level. Do not use if not level. To remove, tap bracket upwards. **SETTING THE PLATFORM.** Scaffold grade wood planking not less than 2" thick should be used. While holding on to fall arrest rope, test platform before standing on it to ensure that set up is secure. Capacity is one worker per 4 feet. Planking should extend beyond the bracket between 6-12 inches. **MAINTENANCE.** Discard immediately if there is any sign of rusting, excessive wear or deformation. Inspect bracket before and after each use. Do not use if exposed to extreme heat or cold. Do not drop from top of building. Always handle with care. When this warning label wears off please request a replacement label.

L051